

Ultrasonic Cleaning Concentrate VP17

Description

The liquid ultrasonic cleaning concentrate VP17 is suitable universally for gold and silver, steel and non-ferrous metals. VP17 comes up to the legal demands as it is over 80% biodegradable according to the OECD method. When applied properly, so far no problems are known during waste water treatment.

Operating conditions

Bath mixture: 1-2%
Temperature: 60-80°C

Form of delivery

Concentrate, liquid

Bath preparation

per liter ready to use bath needed:
10 – 20 ml Ultrasonic cleaning concentrate
VP17

Special hints

With new application, the heated up cleaning liquid must be vented through examine “without goods” approx. 1-5 minutes.

Storage

Store it closed. No further conditions.

Risks/Disposal

Used solutions should be disposed of by a specialist company who will treat it before discharging. Check with the local water authority for permitted discharge levels.

**Please note our
Safety Data Sheet!**