

Ultrasonic Cleaner RAPID JE811

Description

Ultra RAPID JE811 is an ultrasonic cleaning agent in powder form, which is suitable for steel and gold. Ultra RAPID comes up to the demands for biodegradation of the RVO to the washing agent law. Ultra RAPID causes no problems during wastewater treatment if applied properly.

Operating conditions

Bath temperature:	60-80°C
Time:	approx. 1-3 minutes

The time necessary for cleaning must be found out through test. Cleaning time over 3 minutes is not recommended

Form of delivery

- Salt

Preparation

Per liter ready to use bath needed:
30–50 g Salt ULTRA RAPID JE811

Special hints

With new application, the heated up cleaning liquid must be vented through examine “without goods” approx. 5-10 minutes

Storage

Keep closed and separate from food and feed in suitable and well-marked containers. The cleaning salt Ultra RAPID JE811 should be stored dry, as it clumps when absorbing moisture.

Risks/Disposal

Used solutions should be disposed of by a specialist company who will treat it before discharging. Check with the local water authority for permitted discharge levels.

**Please consider our
Safety Data Sheet!**